


# Basic unit

No. 100000087\_887300016\_1000001050

dated: 04/16




## Basic unit

dated: 04/16

No. 100000087\_887300016\_1000001050

Item no.	Description	Article no.	Quantity
-	Set of rollers 2" - 6"	887307000	1
-	Measuring tape	1500000134	1
-	Lower rollers 2" - 2.1/2"	887307300	1
-	Lower rollers 3" - 6"	887307400	1
-	Upper roller 2" - 6"	887307200	1
-	Set of rollers 3" - 6"	887308000	1
-	Set of rollers 8" - 12"	887309000	1
3	Safety cover	887300300	1
7	Motor + gear cpl. 110V Rogroover	1500001171	1
7	Motor + gear cpl. 230V Rogroover	887300700	1
13	Support foot	887301300	4
15	Base	887301500	1
16	Jockey pulley holder assembly	887330000	1
17	Electric link	887301700	1
18	Intermediate link	887301800	1
19	Shaft link	887301900	1
21	Rear cover	887302100	1
22	Roller bearing 32010	887302200	1
23	Main shaft	887302300	1
26	Bushing ø80	887302600	1
27	United head	887302700	1
28	Bushing ø75	887302800	1
29	Needle bearing 4074109	887302900	1
30	Plane needle bearing 889109	887303000	1
31	Fore cover	887303100	1
33	Main shaft fastening nut	887303300	1
35	Oil pump assembly without handle	887320000	1
41	Adjust screw	887304100	1
43	Guide rail bar	887304300	1
47	Slide	887304700	1
49	Roller frame	887304900	1
50	Pinch roller shaft	887305000	1
53	Needle bearing 4084105	887305300	1
54	Pinch roller holder equipment set	887306700	1
70	switch Rogroover 12"	1500001498	1

**IMPORTANT!** To assure safety and reliability, repairs, maintenance and adjustment must be preformed by ROTHENBERGER Kelkheim or authorized Service-Centers. Always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline



## Oil pump

No. 1000000087\_887300016\_1000001050

dated: 06/14


Item no.	Description	Article no.	Quantity	Price (€)
2	Bead flange	887320200	1	o.r.
3	Limit locking nut	887320300	1	o.r.
4	Limit nut	887320400	1	o.r.
7	Copper ring DIN 7603 A 12 x 16 x 1,5 mm	1500000695	1	o.r.
15	Limit piston	887321500	1	o.r.
17	Y-type piston ring Und48X63X10	887321700	1	o.r.
18	Small piston ring	887321800	1	o.r.
19	Scraper seal	887321900	1	o.r.
22	Hexagonal cylinder cover	887322200	1	o.r.
26	Relief valve screw	887322600	1	o.r.
29	Relief valve nut	887322900	1	o.r.
30	Relief valve handle	887323000	1	o.r.
39	New safety valve spring	887323900	1	o.r.
44	Oil drain steeper	887324400	1	o.r.
45	Connecting plate	887324500	1	o.r.
46	Handle seat with 2 Pin roll	887324600	1	o.r.
47	Retaining washer 4 DIN 6799	70081	2	o.r.
48	Pin roll	887324800	1	o.r.
48.1	Retaining washer 6 DIN 6799	FF56766	1	o.r.
49	Handle	887324900	1	o.r.
50	Pump body	887325000	1	o.r.
51	Set Cilindro hexa.	887306900	1	o.r.
52	Drain valve set	887307100	1	o.r.

**IMPORTANT!** To assure safety and reliability, repairs, maintenance and adjustment must be performed by ROTHENBERGER Kelkheim or authorized Service-Centers. Always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline

**Tel.** +49 6195 - 800 **8200**

**Fax:** +49 6195 - 800 **7491**

✉ [service@rothenberger.com](mailto:service@rothenberger.com)



**Jockey pulley holder No. 1000000087\_887300016\_1000001050**

dated: 06/14



Item no.	Description	Article no.	Quantity	Price (€)
5	Guide roller	887330500	1	o.r.
6	Guide roller shaft	887330600	1	o.r.
7	Guide block	887330700	1	o.r.
9	Roller frame	887330900	1	o.r.
11	Handwheel	887331100	1	o.r.
12	Axle M14	887331200	1	o.r.
13	Screw slider	887331300	1	o.r.

**IMPORTANT!** To assure safety and reliability, repairs, maintenance and adjustment must be performed by ROTHENBERGER Kelkheim or authorized Service-Centers. Always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline

**Tel.** +49 6195 - 800 **8200**

**Fax:** +49 6195 - 800 **7491**

✉ [service@rothenberger.com](mailto:service@rothenberger.com)



**Pipe support stand****No. 1000000087\_887300016\_1000001050****dated: 06/14**

<b>Item no.</b>	<b>Description</b>	<b>Article no.</b>	<b>Quantity</b>	<b>Price (€)</b>
4	Triangle bracket	887310400	1	o.r.
5	Stopping block A	887310500	2	o.r.
6	Bracket pipe	887310600	2	o.r.
7	Guide column	887310700	2	o.r.
10	Stopping block B	887311000	2	o.r.
12	Adjust screw cap	887311200	3	o.r.
13	Handle	887311300	1	o.r.
15	Triangle bracket base	887311500	1	o.r.
16	Bearing 6205	887311600	4	o.r.
19	Pipe support stand	1500000133	4	o.r.

**IMPORTANT!** To assure safety and reliability, repairs, maintenance and adjustment must be preformed by ROTHENBERGER Kelkheim or authorized Service-Centers. Always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline

**Tel.** +49 6195 - 800 **8200**

**Fax:** +49 6195 - 800 **7491**

✉ [service@rothenberger.com](mailto:service@rothenberger.com)